



2 Executive Park Drive
Billerica, MA 01862
800-323-2251, FAX: 800-550-4922

TANGO

Cleaning Procedures for Used and Damaged Whiteboards

TANGO Cleaning Procedures for Used & Damaged Whiteboards



Used and Damaged Whiteboards:

Those boards that have been damaged and worn will receive an extended life by using Tango Graffiti and Multi-Purpose Cleaning Paste. Whiteboards by design are a wear item with a certain life span. Use Tango Graffiti and Multi-Purpose Cleaning Paste to reclaim them back to “White” and extend the life of the board by the following cleaning procedure:

1. Use a damp cloth to apply Tango Graffiti and Multi-Purpose Cleaning Paste, rub briskly and wipe off.
2. Spray board with water and wipe off all residues. Reapply if necessary to remove any remaining residue.

Use and Care of New Whiteboards:

Tango is not recommended for use on new whiteboards.

1. Clean new board prior to first use with mild soap and water (do not use abrasive cleaners or Tango Graffiti and Multi-Purpose Cleaning Paste). Rinse and dry thoroughly with a soft cloth.
2. Use only Dry-Erase or Expo Markers. Other markers may permanently damage the writing surface. For best erasing results, replace markers at least once a year.
3. Use a clean eraser to remove dry-erase ink from the board surface. Occasionally, use a Marker Board Cleaner to remove grease, dirt and dry-erase residue that may build up on the board surface.
4. Avoid leaving marks on the board surface for prolonged periods. Dry-erase ink becomes difficult to erase over time, especially when exposed to direct sunlight and high humidity.
5. Do not use adhesive tape of any kind on the board surface.